


n°	Article	Quantité utilisée
3	334473 TAPPING SCREW (W/SP. WASHER)D3X20(BLACK)	4
4	334429 COVER (A)	1
5	334430 GEAR BOX ASS'Y	1
6	334431	1
7	331881 NUT	1
8	334432 SPRING (A)	1
9	334433 THRUST WASHER	1
10	334434 FRONT CASE	1
11	333516 CLICK SPRING	1
12	333539 PIN SET (6 PCS.)	6
13	331909 WASHER (A)	1
14	331903 LOCK RING (A)	1
15	331888 NEEDLE ROLLER SET (6PCS.)	6
16	331904 LOCK CAM	1
17	333517 CARRIER	1
18	333518 PLANET GEAR (C) SET (5 PCS.)	5
19	333519 RING GEAR	1
20	331892 WASHER (A)	1
21	331893 REAR CASE	1
22	331894 SHIFT ARM	1
23	330579 SCREW SET D2X3.5 (2 PCS.)	2
24	320087 SCREW SET M3X12 (4 PCS.)	4
25	331897 PINION (C)	1
26	333520 PLANET GEAR (B) SET (4 PCS.)	4
27	333521 SLIDE RING GEAR	1
28	335296 STOPPER (A)	2
29	333523 STOPPER SPRING	2
30	333524 PINION (B)	1
31	331926 NEEDLE BEARING SET (4 PCS.)	4
32	334441 PLANET GEAR (A) SET (4 PCS)	4
33	334435 FIRST RING GEAR	1
34	322988 WASHER (B)	1
35	331902 MOTOR SPACER	1
36A	360976 ARMATURE & PINION SET 14.4V (OLD 360931)	1
37	334442 MAGNET	1
38	334436 BRUSH BLOCK	1
39	999054 CARBON BRUSH 5X6X11.5 (1 PAIR)	2
40	319918 BRUSH CAP	2

n°	Article	Quantité utilisée
41	334447 HOUSING (A+B) SET	1
42	334450 LED HOLDER	1
43	334443 FERRITE CORE	1
44	331907 PUSHING BUTTON	1
45	334267 SHIFT KNOB (OLD 333527)	1
46	334451 DC-SPEED CONTROL SWITCH	1
47	959140 CONNECTOR 50091 (10 PCS.)	1
48	320287 HOOK ASS'Y	1
49	320288 V-LOCK NUT M5	1
50	958715 TAPPING SCREW D4X10	2
51	996118 HOLDER SPRING	2
52	323003 TERMINAL	1
53	320997 TERMINAL PIECE	1
54	322995 TERMINAL	1
55	306952 STRAP (BLACK)	1
56	313687 TAPPING SCREW (W/FLANGE) D3X16 (BLACK)	1
58	319926 HOOK SPRING	1
59	320881 SPECIAL SCREW M5 (A)	1
60	326824 BATTERY BCL 1430 (EUROPE,AUS,NZL)	2
61	334720 SUMI TUBE	1
501	323230 CASE	1
504	331906 SIDE HANDLE	1
601	303709 DEPTH GAUGE	1



Rev.4

形 名
DS14DL2